## **Double Swivel**



Do not need to change existing filling hoses or filling connectors. Connect the Double Swivel between the hose and the connector. This enables you to fill bottles with top or side outlet cylinder valves. The rotation is around the axial and vertical axes.

Standard end connections (threads) are 3/8"BSPP or 1/4"NPT but can be customised.

Adiabatic compression test R2008-R-287



